



Proper Tagging of Medication with Intelliguard® RFID Smart Tags

CORRECT



Apply horizontally with clear adhesive over manufacturers' labeling



Tag with clear adhesive



Apply horizontally on location shown. Tag should lie flat on front of box



Apply vertically at the edge of the bag with clear adhesive on bag and tag at the top of the bag



Apply horizontally with clear adhesive over the manufacturers' labeling

INCORRECT



DO NOT apply vertically



DO NOT apply on the edge of the box nor on the side of the box



DO NOT apply in the center of the packaging



DO NOT apply vertically on the syringe

Proper Tagging of Medication with Intelliguard® RFID Smart Tags

CORRECT



Apply horizontally with clear adhesive over manufacturers' labeling



Apply vertically at the end of the tube with clear adhesive on the tube and tag hanging below



Apply horizontally near the top with clear adhesive on the bag and tag hanging

INCORRECT



DO NOT apply vertically



DO NOT apply vertically with tag against metal tube



DO NOT apply in the center of the packaging